

HOW TO UPGRADE YOUR WIRELESS ROUTER'S FIRMWARE

(and why you should replace your router if it's no longer supported)

CIPR

CHARTERED INSTITUTE
OF PUBLIC RELATIONS



Before you begin, make sure you have access to a computer with an internet connection and a printer.

Step 1: Check Router Compatibility.

- Verify the make and model of your wireless router.
- Visit the manufacturer's website and search for firmware updates for your router model.
- Ensure that the firmware update is compatible with your router.

Step 2: Download the Firmware.

- Go to the manufacturer's website and locate the support or downloads section.
- Search for your router model and locate the firmware update file.
- Download the latest firmware version onto your computer.

Step 3: Access the Router's Configuration Page.

- Connect your computer to the router via Wi-Fi or an Ethernet cable.
- Open your preferred web browser (Chrome, Edge, Safari, etc.)
- In the address bar, type in your router's IP address. This is usually something like 192.168.0.1 or 192.168.1.1. If you need clarification, check the label on your router or consult your router's manual.
- Enter your username and password. If you have yet to change these, the default credentials can usually be found in the router's manual or on a label on the router itself.

Step 4: Back Up Your Router's Settings.

- Once logged in to the router's configuration page, locate the "Backup" or "Settings" section. This will vary depending on your router's interface. Again, this will vary depending on your router's interface.
- Follow the instructions to create a backup of your router's current settings.

***NB** This step is crucial in case any issues arise during the firmware upgrade process.*

HOW TO UPGRADE YOUR WIRELESS ROUTER'S FIRMWARE

(and why you should replace your router if it's no longer supported)

CIPR

CHARTERED INSTITUTE
OF PUBLIC RELATIONS

Step 5: Upgrade the Firmware

- In the router's configuration page, find the firmware upgrade section.
- Click the "Browse" or "Choose File" button to locate the firmware file you downloaded in Step 2. Again, this will vary depending on your router's interface.
- Select the firmware file and click "Upload" or "Upgrade" to start the installation process.
- Wait for the firmware update to complete. Do not interrupt the process or power off the router during this time.
- The router may automatically restart once the firmware upgrade is finished.

Step 6: Restore Router Settings

- After the router has rebooted, revisit the router's configuration page using the IP address from Step 3.
- Navigate to the settings or restore section.
- Locate the backup file you created in Step 4.

- Follow the instructions to restore your previous settings.
- This step ensures that your customized configurations, such as Wi-Fi network name and password, are retained.

Step 7: Verify Firmware Update

- Once the settings have been restored, confirm that the firmware has been successfully updated.
- Check the router's configuration page or the manufacturer's website to ensure you are running the latest firmware version.

Congratulations! You have successfully upgraded your wireless router's firmware. Feel free to print this guide for future reference.

Replacing Your Router if it's No Longer Supported

In some cases, manufacturers may discontinue support for older router models, which means they will no longer release firmware updates. If your router falls into this category and is no longer supported, consider replacing it with a newer model.

Here are a few reasons why:

Security: Without firmware updates, your router may become vulnerable to new security threats. Malicious actors are constantly finding new ways to exploit vulnerabilities in outdated firmware. Upgrading to a supported router ensures that you receive regular security patches and protection against emerging threats.

Performance and Features: Newer routers often have improved performance capabilities and additional features. Upgrading to a more recent model can provide better Wi-Fi speeds, enhanced range, and advanced settings that enhance your overall network experience.

Compatibility: As technology advances, compatibility with newer devices becomes a concern. Older routers may need help to support the latest Wi-Fi standards or have limitations that hinder connectivity. By upgrading to a supported router, you can ensure seamless compatibility with current and future devices.